

Pellon® Products

Application / Description

Style Names

STABILIZERS

- 30 Pellon® Lightweight
- 40 Pellon® Midweight
- 50 Pellon® Heavyweight
- 65 Pellon® Extra Heavyweight
- *926 Extra Firm
- 70 Peltex® Sew-in Ultrafirm
- 808 Craft-Fuse®
- 809 Decor-Bond®
- 71F Peltex® 1-Sided Ultrafirm
- 72F Peltex® 2-Sided Ultrafirm

Light, crisp support for kitchen projects, fashion accessories & more. White.

Crisp support in place mats, needlecraft backings. White & Black.

Extra body in craft & home decorating projects. White.

Firm body to stiffen visor brims, drapery headers. White.

Firm & stable, yet soft support for crafts & home decor. White.

Multipurpose, ultrafirm. For fabric bowls & boxes. Use in place of cardboard. White & Black.

Crisp iron-on craft backing. Adds body & durability to fabric items, e.g. kitchen & personal accessories, wall hangings. White.

Firm iron-on craft backing. Adds extra crispness to back of place mats, director chairs, lampshades & drapery headers. White.

Use for accessories, purse handles, back packs, where firm support is needed. White.

Use in fabric bowls, boxes, fabric postcards & in place of cardboard. White.

FUSIBLE WEBS (ADHESIVES)

- 725 Heavy Duty Wonder-Under®
- 800 Clear-Fuse®
- 805 Wonder-Under®
- 807 Wonder-Web®

Heavier, with paper backing & double the adhesive of original Wonder-Under®.

For appliques & hems in denim, canvas & heavy fabrics. For thick-to-thin combinations. Paper backing eases application.

Easy-to-use clear paper backing with an even, firm fusible. Makes cutting patterns easier.

Paper backing. Fuse fabric to fabric or a porous surface. For most fabric weights. For heavier fabrics, use 725 Heavy Duty Wonder-Under®.

Paper backing eliminates separate transfer sheet; draw on backing with pencil or pen. Fuse hems, facings, appliques & trims.

Unsupported web replaces sewing & gluing. For areas layered between two fabrics, e.g. hems & larger areas.

QUILTING AIDS

- 820 Quilter's Grid™ 1" Grid
- *821 Quilter's Grid™ OnPoint

Lightweight. Simplifies quilt assembly. Place squares, right side up, on top of grid. Iron in place. Sew quilt by the row.

For watercolor quilts & fabric-square designs.

Same as Quilter's Grid™, except printed squares are turned at a 45° angle.

FLEECE

- 987F Pellon® Fusible Fleece
- 988 Pellon® Sew-in Fleece
- TP970 Thermolam® Plus
- TP971F Fusible Thermolam® Plus

Adds low-loft body to craft home decor, quilts, handbags & totes.

Low-loft polyester fleece. Use where a little padding is needed, when quilting or crafting.

Heavily needled polyester fleece. Thicker than 988 Fleece. Gives more loft to project.

A heavier-needled fleece. Adds body, firmness & loft to diaper bags & totes.

PATTERN-TRACING MATERIALS

- 810 Tru-Grid™
- 830 Easy Pattern

1" printed graph for altering, duplicating or scaling patterns. Stable for ease of drawing. White.

No-line, no-dots material for altering, duplicating or tracing patterns. White.

MACHINE-STITCHING STABILIZERS

- 541 Wash-n-Gone™
- 806 Stitch-n-Tear®

All-temp, water-soluble stabilizer. Use for machine embroidery, lighter-weight fabrics or machine lacework. Washes away completely.

Tear-away stabilizer for machine stitching, machine embroidery, applique, cut-work & monogramming.